

Инв. N подл.	Погн и гата	Взам. инв. N			
R4.04703.4.0.33	01290250				
	11	Питание приборов 15 В			
	02x1'/11x7'	11x1'	1	11x1	UG1
		11x2'	2	11x2	
	N 02x4'	11x3'	3 ♀	11x3	UG1
	11x9'	11x4'	4 ♂	11x4	
	+U	11x5'	5	11x5	UG1
	-U	11x6'	6	11x6	UG1
	11x1'/11x13'	11x7'	7	11x7	UG2
		11x8'	8	11x8	
	N 11x4'	11x9'	9 ♀	11x9	UG2
	11x15'	11x10'	10 ♂	11x10	
	+U	11x11'	11	11x11	UG2
	-U	11x12'	12	11x12	UG2
	11x7'/11x19'	11x13'	13	11x13	UG3
		11x14'	14	11x14	
	N 11x10'	11x15'	15 ♀	11x15	UG3
	11x21'	11x16'	16 ♂	11x16	
	+U	11x17'	17	11x17	UG3
	-U	11x18'	18	11x18	UG3
	11x13'/11x25'	11x19'	19	11x19	UG4
		11x20'	20	11x20	
	N 11x16'	11x21'	21 ♀	11x21	UG4
	11x27'	11x22'	22 ♂	11x22	
	+U	11x23'	23	11x23	UG4
	-U	11x24'	24	11x24	UG4
	11x19'/11x31'	11x25'	25	11x25	UG5
		11x26'	26	11x26	
	N 11x22'	11x27'	27 ♀	11x27	UG5
	11x33'	11x28'	28 ♂	11x28	
	+U	11x29'	29	11x29	UG5
	-U	11x30'	30	11x30	UG5
	11x25'/11x37'	11x31'	31	11x31	UG6
		11x32'	32	11x32	
	N 11x28'	11x33'	33 ♀	11x33	UG6
	11x39'	11x34'	34 ♂	11x34	
	+U	11x35'	35	11x35	UG6
	-U	11x36'	36	11x36	UG6
	11x31'/11x43'	11x37'	37	11x37	UG7
		11x38'	38	11x38	
	N 11x34'	11x39'	39 ♀	11x39	UG7
	11x45'	11x40'	40 ♂	11x40	
	+U	11x41'	41	11x41	UG7
	-U	11x42'	42	11x42	UG7
	11x37'	11x43'	43	11x43	UG8
		11x44'	44	11x44	
	N 11x40'	11x45'	45 ♀	11x45	UG8
		11x46'	46 ♂	11x46	
	+U	11x47'	47	11x47	UG8
	-U	11x48'	48	11x48	UG8
		11x49'	49	11x49	
	11x50'	50	11x50		
	Резерв				
		1			
		2			
		58			

02	Расход воды			4VB61F01P01
01x1'/11x1'	02x1'	1	02x1	PF1
	02x2'	2	02x2	
N 01x4'	02x3'	3	02x3	PF1
11x3'	02x4'	4	02x4	
05x3'	02x5'	5	02x5	
4VB61F01B01.1	02x6'	6	02x6	PF1
4VB61F01B01.2	02x7'	7	02x7	PF1
4VB62F01B01.1	02x8'	8	02x8	PF1
4VB62F01B01.2	02x9'	9	02x9	PF1
4VB63F01B01.1	02x10'	10	02x10	PF1
4VB63F01B01.2	02x11'	11	02x11	PF1
4VB64F01B01.1	02x12'	12	02x12	PF1
4VB64F01B01.2	02x13'	13	02x13	PF1
	02x14'	14	02x14	
	02x15'	15	02x15	
	02x16'	16	02x16	
	02x17'	17	02x17	
	02x18'	18	02x18	
05	F воды на входе в 4UX21H01			4UX31F01P01
06x1'/13x6'	05x1'	1	05x1	PF4
	05x2'	2	05x2	
N 02x5'	05x3'	3	05x3	PF4
06x3'	05x4'	4	05x4	
4UX31F01B01.1	05x5'	5	05x5	PF4
4UX31F01B01.2	05x6'	6	05x6	PF4
	05x7'	7	05x7	
	05x8'	8	05x8	
06	F воды на входе в 4UX41H01			4UX41F01P01
06x1'/10x1'	06x1'	1	06x1	PF5
	06x2'	2	06x2	
N 06x4'	06x3'	3	06x3	PF5
10x3'	06x4'	4	06x4	
4UX41F01B01.1	06x5'	5	06x5	PF5
4UX41F01B01.2	06x6'	6	06x6	PF5
	06x7'	7	06x7	
	06x8'	8	06x8	
09	Расход воды			4UX31F03P01
05x1'/09x1'	09x1'	1	09x1	PF8
	09x2'	2	09x2	
N 05x4'	09x3'	3	09x3	PF8
09x3'	09x4'	4	09x4	
4UX31F03B01.1	09x5'	5	09x5	PF8
4UX31F03B01.2	09x6'	6	09x6	PF8
	09x7'	7	09x7	
	09x8'	8	09x8	
10	Расход воды			4UX12F02P01
A91 09x1'	10x1'	1	10x1	PF9
	10x2'	2	10x2	
N 09x4'	10x3'	3	10x3	PF9
	10x4'	4	10x4	
4UX12F02B01.1	10x5'	5	10x5	PF9
4UX12F02B01.2	10x6'	6	10x6	PF9
	10x7'	7	10x7	
	10x8'	8	10x8	

[illegible]

1 Ряды зажимов N3,4 – резерв.

ИНВ. N погл. R4.04703.4.0.33

АРХИВНЫЙ ЭКЗЕМПЛЯР